


14. EXPLODED VIEW & REPLACEMENT PART LIST


14.1 EXPLODED VIEW



#6	BATTERY COVER ASSY	I	ACGA0021601		
#5	COVER ASSY, REAR	I	ACGM0107401		
#4	COVER ASSY, FRONT	I	ACGK0105701		
#3	COVER ASSY, SLIDE(LOWER)	I	ARDY0004701		
#2	COVER ASSY, SLIDE(UPPER)	I	ACGS0016701		
#1	COVER ASSY SLIDE	I	ACGQ0023501		
NO.	DESCRIPTION	Q'TY	ACGS0015801		REMARK

75	TAPE, PROTECTION	I	MTAB0245201		
74	RAIL ASSY, SLIDE	I	ARDY0004801		
73	DECO, CAMERA(MIRROR)	I	MDAD0036601		
72	TAPE, DECO	I	MTAA0156401		
71	DECO, CAMERA(PLATE)	I	MDAD0035601		
70	TAPE, DECO	I	MTAA0153101		
69	COVER, BATTERY	I	MCJA0058201		
68	SCREW MACHINE	4	GMZZ0019003		
67	CAP, SCREW	I	MCCH0130401		
66	DECO(배면 SHEET)	I	MDAY0039001		
65	SCREW MACHINE	6	GMEY0011201		
64	CAP, MULTIMEDIA CARD	I	MCCG0011001		
63	WINDOW, CAMERA	I	MWAE0032601		
62	DECO, CAMERA	I	MDAD0035501		
61	TAPE, WINDOW	I	MTAD0081401		
60	CAP, MOBILE SWITCH	I	MCCF0051501		
59	INSULATOR(BUTTON)	2	MTAB0213101		
58	BUTTON, CAMERA	I	MBJL0057201		
57	BUTTON, VOLUME	I	MBJL0052701		
56	PAD, CAMERA	I	MPBT0055801		
55	PAD, CONNECTOR(CAMERA)	I	MPBU0023201		
54	CAP, EARPHONE JACK	I	MCCC0052601		
53	INSULATOR(MMI CAP)	I	MTAB0228001		
52	COVER, REAR	I	MCJN0080801		
51	SPRING, LOCKER	I	MSDC0008301		
50	LOCKER, BATTERY	I	MLEA0044601		
49	LABEL, A/S	I	MLAB0004801		
48	TAPE, SHIELD	I	MTAC0069401		
47	FRAME	I	MFEZ0013501		
46	FILTER, SPEAKER	I	MFBG0039301		
45	SPEAKER	I	SUST0024801		
44	PAD, SPEAKER	I	MPBN0054401		
43	TAPE, FLASH LENS	I	MTAD0085201		
42	LENS, FLASH	I	MLCE0009101		
41	PAD, FLASH LED	I	MPBZ0204001		
40	ANTENNA, GSM, FIXED	I	SNGF0035302		
39	PCB ASSY, FLEXIBLE	I	SACY0073801		
38	CAMERA	I	SVCY0017101		
37	VIBRATOR, MOTOR	I	SJMY0008405		
36	PCB ASSY, MAIN	I	SAFY0257201		
35	CAN ASSY, SHIELD	I	ACKA0008601		
34	PCB ASSY, FLEXIBLE	I	SACY0073701		
33	KEYPAD, MAIN	I	MKAG0006401		
32	SCREW MACHINE	I	GMZZ0019007		
31	PAD, CONNECTOR(F-KEY)	I	MPBU0023301		
30	TAPE, MOTOR	I	MTAF0016101		
29	COVER, FRONT	I	MCJK0083901		
28	TAPE, DECO	I	MTAA0153001		
27	DECO, FRONT	I	MDAG0034601		
26	CAP, SCREW	2	MCCH0127901		
25	SCREW MACHINE	6	GMZZ0026401		
24	RAIL ASSY, SLIDE	I	ARDY0004701		
23	PAD	I	MPBZ0208401		
22	PAD	I	MPBZ0211901		
21	TAPE, SHIELD	2	MTAC0066801		
20	RECEIVER	I	SURY0013401		
19	PCB ASSY, FLEXIBLE	I	SACY0075601		
18	INSULATOR	I	MIDZ0162301		
17	INSULATOR(SHORT 쪽)	I	ADCA0079701		
16	PCB ASSY, KEYPAD	I	SAEY0061501		
15	DOMESHEET, SUB	I	ADCA0079701		
14	KEYPAD ASSY, SUB	I	AKAD0001001		
13	LCD MODULE	I	SVLM0027801		
11	MAGNET, SWITCH	I	MMAA0000901		
10	STOPPER	2	MSGY0024001		
9	PAD, RCV(FILTER)	I	MFBG0025001		
8	INSULATOR(TOP SIDE)	I	MIDZ0173601		
7	INSULATOR(SHORT 쪽)	I	MIDZ0162201		
6	PAD LCD	I	MPBG0072801		
5	COVER SLIDE UPPER	I	MCJW0016901		
4	TAPE WINDOW	I	MTAD0081301		
3	MAIN WINDOW LCD	I	MWAC0094201		
2	SLIDE UPPER PROTECTION	I	MTAB0213001		
1	KEYPAD PROTECTION	I	MIDZ0168202		
NO.	DESCRIPTION	Q'TY	DRAWING NO.		REMARK

ASS'Y EXPLODED VIEW



9	BATTERY COVER ASSY	1	ACGA0021601	
8	COVER ASSY, REAR	1	ACGM0107401	
7	COVER ASSY, FRONT	1	ACGK0105701	
6	PCB ASSY MAIN	1	SAFY0257201	
5	BUTTON ASSY MAIN	1	MKAG0006401	
4	SLIDE HINGE ASSY	1	ARDY0004701	
3	PCB ASSY SUB	1	SAEY0061501	
2	BUTTON ASSY SUB	1	AKAD0001001	
1	COVER ASSY, SLIDE(UPPER)	1	ACGS0016701	
NO.	DESCRIPTION	Q'TY	ACGS0015801	REMARK

14. EXPLODED VIEW & REPLACEMENT PART LIST

14.2 Replacement Parts <Mechanic component>

Note: This Chapter is used for reference, Part order is ordered by SBOM standard on GCSC

Level	Location No.	Description	Part Number	Spec	Color	Remark
1		GSM(SLIDE)	TGLL0016401		Black	
2	AAAY00	ADDITION	AAAY0293801		Black	
3	ACGA00	COVER ASSY,BATTERY	ACGA0021601		Black	I, #6
4	ARDY00	RAIL ASSY,SLIDE	ARDY0004801	CAMERA COVER	TITAN GRAY	74
4	GMZZ00	SCREW MACHINE	GMZZ0019003	3.5 mm,1.5 mm,MSWR3 ,N ,+ , - ,NYLOK Coating (ZnB-BLACK)	Black	68
4	MCCH00	CAP,SCREW	MCCH0130401	MOLD, PC LUPOY SC-1004A, , , , ,	Black	67
4	MCJA00	COVER,BATTERY	MCJA0058201	MOLD, PC LUPOY SC-1004ML, , , , ,	Black	69
4	MDAD00	DECO,CAMERA	MDAD0035601	COMPLEX, (empty), 0.3, , , ,	Transparent	71
4	MDAD01	DECO,CAMERA	MDAD0036601	ELECTROFORMING, Cu, 0.3, , , ,	Transparent	73
4	MDAY00	DECO	MDAY0039001	CUTTING, NS, 1.05mm, , , ,	Black	66
4	MTAA00	TAPE,DECO	MTAA0153101	COMPLEX, (empty), , , , ,	Without Color	70
4	MTAA01	TAPE,DECO	MTAA0156401	COMPLEX, (empty), , , , ,	Without Color	72
4	MTAB00	TAPE,PROTECTION	MTAB0245201	COMPLEX, (empty), 0.35, , , ,	Without Color	76
2	APEY00	PHONE	APEY0562901		Black	
3	ACGM00	COVER ASSY,REAR	ACGM0107401		Black	H, #5
4	MBJL00	BUTTON,SIDE	MBJL0052701	COMPLEX, (empty), , , , ,	Black	57
4	MBJL01	BUTTON,SIDE	MBJL0057201	COMPLEX, (empty), , , , ,	Black	58
4	MCCC00	CAP,EARPHONE JACK	MCCC0052601	COMPLEX, (empty), , , , ,	Black	54
4	MCCF00	CAP,MOBILE SWITCH	MCCF0051501	CUTTING, NS, 0.2, , , ,	Black	60
4	MCCG00	CAP,MULTIMEDIA CARD	MCCG0011001	MOLD, PC LUPOY SC-1004ML, , , , ,	Black	64
4	MCJN00	COVER,REAR	MCJN0080801	MOLD, PC LUPOY SC-1004ML, , , , ,	Black	52
4	MDAD00	DECO,CAMERA	MDAD0035501	ELECTROFORMING, Cu, 0.3, , , ,	Silver	62
4	MFBC00	FILTER,SPEAKER	MFBC0039301	COMPLEX, (empty), , , , ,	Black	46
4	MFEZ00	FRAME	MFEZ0015501	PRESS, STS, , , , ,	Silver	47
4	MIDZ00	INSULATOR	MIDZ0179801	5PI X 1.5PI X 0.05T	Yellow	
4	MLAB00	LABEL,A/S	MLAB0004801	PRINTING, (empty), , , , ,	Without Color	49

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
4	MLCE00	LENS,FLASH	MLCE0009101	MOLD, PC LUPOY SC-1004ML, , , ,	Black	42
4	MLEA00	LOCKER,BATTERY	MLEA0044601	MOLD, PC LUPOY SC-1004ML, , , ,	Black	50
4	MPBN00	PAD,SPEAKER	MPBN0054401	COMPLEX, (empty), , , ,	Black	44
4	MPBT00	PAD,CAMERA	MPBT0055801	COMPLEX, (empty), , , ,	Black	56
4	MPBU00	PAD,CONNECTOR	MPBU0023201	COMPLEX, (empty), , , ,	Black	55
4	MPBZ00	PAD	MPBZ0204001	CUTTING, NS, 1.4, , , ,	White	41
4	MSDC00	SPRING,LOCKER	MSDC0008301		Without Color	51
4	MTAB00	TAPE,PROTECTION	MTAB0213101	COMPLEX, (empty), 0.35, , , ,	Without Color	59
4	MTAB01	TAPE,PROTECTION	MTAB0228001	COMPLEX, (empty), 0.35, , , ,	Without Color	53
4	MTAC00	TAPE,SHIELD	MTAC0069401	COMPLEX, (empty), , , , ,	Silver	48
4	MTAD00	TAPE,WINDOW	MTAD0081401	COMPLEX, (empty), , , , ,	Without Color	61
4	MTAD01	TAPE,WINDOW	MTAD0085201	COMPLEX, (empty), , , , ,	Without Color	43
4	MWAE00	WINDOW,CAMERA	MWAE0032601	MOLD, Tempered Glass, , , , ,	Black	63
3	ACGQ00	COVER ASSY,SLIDE	ACGQ0023501		Black	#1
4	ACGK00	COVER ASSY,FRONT	ACGK0105701		Black	G, #4
5	MCJK00	COVER,FRONT	MCJK0083901	MOLD, PC LUPOY SC-1004ML, , , , ,	Black	29
5	MDAG00	DECO,FRONT	MDAG0034601	MOLD, POM LUCAL FW-700A, , , , ,	Black	27
5	MICZ00	INSERT	MICZ0021601	M1.4XL2.5	Silver	
5	MPBU00	PAD,CONNECTOR	MPBU0023301	COMPLEX, (empty), , , , ,	Black	31
5	MTAA00	TAPE,DECO	MTAA0153001	COMPLEX, (empty), , , , ,	Without Color	28
5	MTAF00	TAPE,MOTOR	MTAF0016101	COMPLEX, (empty), , , , ,	Without Color	30
4	ACGS00	COVER ASSY, SLIDE(UPPER)	ACGS0016701		Black	A, #2
5	MCJW00	COVER,SLIDE(UPPER)	MCJW0016901	CASTING, Al Alloy, , , , ,	Black	5
5	MFBB00	FILTER,RECEIVER	MFBB0025001	COMPLEX, (empty), , , , ,	Without Color	9
5	MIDZ00	INSULATOR	MIDZ0162201	COMPLEX, (empty), , , , ,	Without Color	
5	MIDZ001	INSULATOR	MIDZ0173601	COMPLEX, (empty), , , , ,	Without Color	8
5	MMAA00	MAGNET,SWITCH	MMAA0000901	G7000 12x2x0.7t	Metal Silver	11

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
5	MPBG00	PAD,LCD	MPBG0072801	COMPLEX, (empty), , , , ,	Without Color	6
5	MSGY00	STOPPER	MSGY0024001	COMPLEX, (empty), , , , ,	Black	
5	MTAD00	TAPE,WINDOW	MTAD0081301	COMPLEX, (empty), , , , ,	Without Color	4
5	MWAC00	WINDOW,LCD	MWAC0094201	MOLD, PMMA HI835M, , , , ,	Without Color	3
4	AKAD00	KEYPAD ASSY,SUB	AKAD0001001	SLIDE FUNCTION	Black	B, 14
4	ARDY00	RAIL ASSY,SLIDE	ARDY0004701		TITAN GRAY	D, #3, 24
5	MIDZ00	INSULATOR	MIDZ0175901	COMPLEX, (empty), , , , ,	Without Color	
5	MIDZ01	INSULATOR	MIDZ0175902	INSULATOR MOVING PLATE	Without Color	
5	MIDZ02	INSULATOR	MIDZ0175903	INSULATOR BUMPER	Without Color	
5	MSGY00	STOPPER	MSGY0024001	COMPLEX, (empty), , , , ,	Black	10
4	GMZZ00	SCREW MACHINE	GMZZ0019007	M1.4,1.5 mm,MSWR3 ,N ,+ , - , NYLOK Coating , , , , , , , , , ,	WHITE SILVER	32
4	GMZZ01	SCREW MACHINE	GMZZ0026401	1.4 mm,1.7 mm,MSWR3(FZW) ,A ,+ , - , , , , ,RWH ,+ ,1.4 ,1.7 ,NYLON ,WHITE ,[empty] ,[empty]	White	25
4	MCCH00	CAP,SCREW	MCCH0127901	MOLD, PC LUPOY SC-1004A, , , , ,	Silver	26
4	MIDZ01	INSULATOR	MIDZ0162201	COMPLEX, (empty), , , , ,	Without Color	7
4	MIDZ02	INSULATOR	MIDZ0162301	COMPLEX, (empty), , , , ,	Without Color	18
4	MIDZ03	INSULATOR	MIDZ0168202	COMPLEX, (empty), , , , ,	Without Color	1
4	MKAG00	KEYPAD,MAIN	MKAG0006401	COMPLEX, (empty), , , , ,	Black	E, 33
4	MLAZ00	LABEL	MLAZ0038303	PRINTING, (empty), , , , ,	White	
4	MPBZ00	PAD	MPBZ0208301	CUTTING, NS, 1.4, , , ,	White	
4	MPBZ01	PAD	MPBZ0208401	CUTTING, NS, 1.4, , , ,	White	23
4	MPBZ05	PAD	MPBZ0211901	CUTTING, NS, 1.4, , , ,	Without Color	22
4	MRDY00	REINFORCE	MRDY0000601	COMPLEX, (empty), , , , ,	White	
4	MTAB00	TAPE,PROTECTION	MTAB0213001	COMPLEX, (empty), , , , ,	Without Color	2
4	MTAC00	TAPE,SHIELD	MTAC0066801	COMPLEX, (empty), , , , ,	Gold	21
4	MTAK00	TAPE,CAMERA	MTAK0009801	COMPLEX, (empty), , , , ,	Black	

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	MIDZ00	INSULATOR	MIDZ0162201	COMPLEX, (empty), , , ,	Without Color	
6	MPBU00	PAD,CONNECTOR	MPBU0024701	COMPLEX, (empty), , , ,	Black	
6	MPBU01	PAD,CONNECTOR	MPBU0024801	COMPLEX, (empty), , , ,	Black	
6	ADCA00	DOME ASSY,METAL	ADCA0079201	KC550 main. 5pi D(LGF)	White	
6	MPBH00	PAD,MIKE	MPBH0037001	COMPLEX, (empty), , , ,	Black	
6	ADCA00	DOME ASSY,METAL	ADCA0079701	KC550 slide. 5pi D	White	15, 17
6	MTAC00	TAPE,SHIELD	MTAC0074101	COMPLEX, (empty), , , ,	Gold	
6	MTAC01	TAPE,SHIELD	MTAC0074102	COMPLEX, (empty), , , ,	Gold	
3	GMEY00	SCREW MACHINE,BIND	GMEY0011201	1.4 mm,3 mm,MSWR3(BK) ,N ,+ ,NYLOK	Without Color	65
3	MLAK00	LABEL,MODEL	MLAK0006301	LG (30.5x21.5 4-1R)	Pearl White	
5	ACKA00	CAN ASSY,SHIELD	ACKA0008601	KC550 SHIELD CAN ASSY	Silver	35
6	MCBA00	CAN,SHIELD	MCBA0031001	PRESS, STS, , , ,	Without Color	
6	MIDZ00	INSULATOR	MIDZ0174501	COMPLEX, (empty), , , ,	Green	
6	MIDZ01	INSULATOR	MIDZ0174701	COMPLEX, (empty), , , ,	Blue	
6	MIDZ02	INSULATOR	MIDZ0174801	COMPLEX, (empty), , , ,	Blue	
6	MTAC00	TAPE,SHIELD	MTAC0072601	COMPLEX, (empty), , , ,	Silver	
5	MLAZ00	LABEL	MLAZ0038301	PID Label 4 Array	Without Color	

14. EXPLODED VIEW & REPLACEMENT PART LIST

<Main component>

Note: This Chapter is used for reference, Part order is ordered by SBOM standard on GCSC

Level	Location No.	Description	Part Number	Spec	Color	Remark
4	SNGF00	ANTENNA,GSM,FIXED	SNGF0035302	3.0 ,-2.0 dBd,, ,internal, GSM900/1800/1900 ,; ,TRIPLE ,-2.0 ,50 ,3.0		40
4	SUSY00	SPEAKER	SUSY0024801	PIN ,8 ohm,90 dB,16 mm,3.4T, Spring Contact ,; , , , , , , ,CONTACT		45
4	SACY00	PCB ASSY,FLEXIBLE	SACY0075601	F-LCD		19
5	SACB00	PCB ASSY,FLEXIBLE,INSERT	SACB0046801	F-LCD		
5	SACE00	PCB ASSY,FLEXIBLE,SMT	SACE0070201	F-LCD		
6	SACC00	PCB ASSY,FLEXIBLE,SMT BOTTOM	SACC0046801	F-LCD		
7	BAT401	BATTERY,CELL,LITHIUM	SBCL0001701	2 V,0.5 mAh,CYLINDER ,Reflow type BB, Max T 1.67, phi 4.8, Pb-Free		
7	C101	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
7	C102	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
7	C103	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
7	C424	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	L101	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
7	L102	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
7	R432	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
7	VA1	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA2	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
6	SACD00	PCB ASSY,FLEXIBLE,SMT TOP	SACD0059701	F-LCD		
7	CN101	CONNECTOR,BOARD TO BOARD	ENBY0039001	54 PIN,0.4 mm,ETC , ,H=1.5, P4S Header		
7	CN102	CONNECTOR,BOARD TO BOARD	ENBY0044601	54 PIN,0.4 mm,STRAIGHT , , , , ,0.40MM ,STRAIGHT ,MALE ,SMD ,[empty] , ,		
6	SPCY	PCB,FLEXIBLE	SPCY0129901	POLYI,0.2 mm,DOUBLE ,F_LCD ,; , , , , , , , ,		
4	SACY01	PCB ASSY,FLEXIBLE	SACY0073701	F_KEY		34
5	SACB00	PCB ASSY,FLEXIBLE,INSERT	SACB0045401	F_KEY		
5	SACE00	PCB ASSY,FLEXIBLE,SMT	SACE0068301	F_KEY		
6	SACC00	PCB ASSY,FLEXIBLE,SMT BOTTOM	SACC0045401	F_KEY		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
7	CN101	CONNECTOR,BOARD TO BOARD	ENBY0043601	20 PIN,0.4 mm,STRAIGHT , , , , ,0.40MM ,STRAIGHT ,MALE ,SMD ,[empty] , ,		
6	SACD00	PCB ASSY,FLEXIBLE,SMT TOP	SACD0057701	F_KEY		
7	AFCAM	SWITCH,TACT	ESCY0005301	1 V,1 A,HORIZONTAL ,1 G, , , ,10C2P ,[empty] ,[empty] ,[empty] , , ,[empty]		
7	C101	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C102	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C103	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
7	C104	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C105	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C106	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C107	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
7	C108	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
7	C109	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	L101	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
7	L102	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
7	L103	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
7	LD101	DIODE,LED,CHIP	EDLH0013701	WHITE ,ETC ,R/TP ,SIDEVIEW , , , ,[empty] ,2.9~3.75 ,30mA , , ,120mW ,[empty] ,[empty] ,2P		
7	LD102	DIODE,LED,CHIP	EDLH0013701	WHITE ,ETC ,R/TP ,SIDEVIEW , , , ,[empty] ,2.9~3.75 ,30mA , , ,120mW ,[empty] ,[empty] ,2P		
7	MIC101	MICROPHONE	SUMY0010603	PIN ,42 dB,4.72*3.76*1.25 ,MEMS MIC , , , ,OMNI ,1.5TO5V , ,SMD		
7	R102	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R103	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	U101	IC	EUSY0362601	SSON004 ,4 ,R/TP ,Hall IC , , ,IC,CMOS		
7	VA101	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA102	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA103	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA104	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA105	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA106	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA107	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		
7	VA108	VARISTOR	SEVY0003601	5.6 V , ,SMD ,100pF ,1005		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
7	VA109	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA110	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA111	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
6	SPCY01	PCB,FLEXIBLE	SPCY0130101	POLYI ,0.2 mm,DOUBLE ,F_KEY ,,,,,,,,,,		
4	SAEY00	PCB ASSY,KEYPAD	SAEY0061501			C, 17
5	SAEB00	PCB ASSY, KEYPAD,INSERT	SAEB0025601			
5	SAEE00	PCB ASSY,KEYPAD,SMT	SAEE0028701			
6	SAEC00	PCB ASSY,KEYPAD,SMT BOTTOM	SAEC0027201			
7	C102	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C103	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
7	C104	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	C105	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	C106	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	C107	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	C108	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , [empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
7	C109	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
7	C110	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
7	CN101	CONNECTOR,FFC/FPC	ENQY0014301	37 PIN,0.3 mm,STRAIGHT , , , , ,0.30MM ,FFC/FPC ,STRAIGHT ,BOTH ,SMD ,[empty] ,[empty] ,		
7	CN102	CONNECTOR,BOARD TO BOARD	ENBY0044701	54 PIN,0.4 mm,STRAIGHT , , , , ,0.40MM ,STRAIGHT ,FEMALE ,SMD ,[empty] , ,		
7	R104	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
7	R106	RES,CHIP,MAKER	ERHZ0000420	150 ohm,1/16W ,J ,1005 ,R/TP		
7	U101	IC	EUSY0230104	CSP ,36 PIN,R/TP ,SUB PMIC,ALC,2LDO_150mA,1.33X , , ,IC,Sub PMIC		
7	VA101	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA102	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA103	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA104	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA105	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA106	VARISTOR	SEVY0001001	14 V ,SMD ,50pF, 1005		
7	VA107	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
7	VA108	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA109	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA110	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA111	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA112	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA113	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
7	VA114	VARISTOR	SEVY0003601	5.6 V ,SMD ,100pF, 1005		
6	SAED00	PCB ASSY,KEYPAD,SMT TOP	SAED0026701			
7	LD101	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	LD102	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	LD103	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	LD104	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	LD105	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	LD106	DIODE,LED,CHIP	EDLH0011901	WHITE ,1608 ,R/TP ,PB-FREE(ZENER)		
7	R101	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R102	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R103	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R105	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R107	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
7	R108	RES,CHIP,MAKER	ERHZ0000402	10 ohm,1/16W ,J ,1005 ,R/TP		
6	SPEY00	PCB,KEYPAD	SPEY0055201	FR-4 ,0.5 mm,BUILD-UP 4 , , , , , , , , , ,		
4	SURY00	RECEIVER	SURY0013401	ASSY ,107 dB,32 ohm,11*07 , , , , , , , ,CONNECTOR ,		20
4	SVCY00	CAMERA	SVCY0017101	CMOS ,MEGA ,5M AF [Micon 1/3.2", MI5130, MIPI, FPCB]		38
4	SVLM00	LCD MODULE	SVLM0027801	MAIN ,240*320 ,42.2*60*1.5t ,262k ,TFT ,TM ,uPD161707 ,		13
		LCD MODULE	SVLM0027802	MAIN ,240*320 ,42.2*60*1.5t ,262k ,TFT ,TM ,uPD161707 ,		
3	SAFY00	PCB ASSY,MAIN	SAFY0257201			F, 36
4	SAFB00	PCB ASSY,MAIN,INSERT	SAFB0085901			
5	SACY00	PCB ASSY,FLEXIBLE	SACY0073801	F_FLASH		39
6	SACE00	PCB ASSY,FLEXIBLE,SMT	SACE0068401	F_FLASH		
7	SACD00	PCB ASSY,FLEXIBLE,SMT TOP	SACD0057801	F_FLASH		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
8	EDLM00	DIODE,LED,MODULE	EDLM0009501	white ,1 LED,2.0x1.6x0.7t ,R/TP ,		
7	SPCY01	PCB,FLEXIBLE	SPCY0130001	POLYI ,0.2 mm,DOUBLE ,F-FLASH ,; , , , , , , , , ,		
5	SJMY00	VIBRATOR,MOTOR	SJMY0008405	3 V ,.08 A,10pi*2.7t ,12mm ,; ,3V , , ,12000rpm , , , ,31ohm		37
4	SAFF01	PCB ASSY,MAIN,SMT	SAFF0173701			
5	SAFC00	PCB ASSY,MAIN,SMT BOTTOM	SAFC0108101			
6	ANT500	ANTENNA,GSM,FIXED	SNGF0036701	3.0 , -2.0 dBd,, ,internal, bluetooth chip ,; ,SINGLE , -2.0 ,50 ,3.0		
6	C203	CAP,CERAMIC,CHIP	ECCH0006201	4.7 uF,6.3V ,K ,X5R ,TC ,1608 ,R/TP		
6	C204	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C205	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C206	CAP,TANTAL,CHIP	ECTH0001704	22 uF,10V ,M ,L_ ESR ,2012 ,R/TP ,; , ,[empty] ,[empty] , ,[empty] , ,2.2X1.25X1.2MM ,[empty] ,[empty] ,[empty]		
6	C207	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C208	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C209	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C210	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C211	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C212	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C213	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C214	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C216	CAP,CERAMIC,CHIP	ECCH0006201	4.7 uF,6.3V ,K ,X5R ,TC ,1608 ,R/TP		
6	C219	CAP,CERAMIC,CHIP	ECCH0006201	4.7 uF,6.3V ,K ,X5R ,TC ,1608 ,R/TP		
6	C221	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C222	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C227	CAP,TANTAL,CHIP	ECTH0005202	100 uF,4V ,M ,L_ ESR ,2012 ,R/TP ,; , ,[empty] ,[empty] , ,[empty] , ,[empty] ,[empty] ,[empty] ,[empty] ,[empty]		
6	C229	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C230	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C231	CAP,TANTAL,CHIP	ECTH0005202	100 uF,4V ,M ,L_ ESR ,2012 ,R/TP ,; , ,[empty] ,[empty] , ,[empty] , ,[empty] ,[empty] ,[empty] ,[empty]		
6	C232	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C233	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C234	CAP,CHIP,MAKER	ECZH0001217	470 nF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C235	CAP,CHIP,MAKER	ECZH0001217	470 nF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C236	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C237	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C238	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C239	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C240	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C241	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C242	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C243	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C244	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C245	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C262	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C263	CAP,TANTAL,CHIP	ECTH0004807	10 uF,10V ,M ,STD ,1608 ,R/TP ; , , [empty] , [empty] , -55TO+125C , , [empty] , [empty] , [empty] , [empty]		
6	C264	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C265	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C266	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C267	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C276	CAP,CERAMIC,CHIP	ECCH0000110	10 pF,50V,D,NP0,TC,1005,R/TP		
6	C278	VARISTOR	SEVY0004301	18 V , ,SMD ,10pF, 1005		
6	C279	CAP,CERAMIC,CHIP	ECCH0000110	10 pF,50V,D,NP0,TC,1005,R/TP		
6	C280	CAP,CERAMIC,CHIP	ECCH0000110	10 pF,50V,D,NP0,TC,1005,R/TP		
6	C301	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C302	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C303	CAP,CHIP,MAKER	ECZH0000901	24 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C304	CAP,CHIP,MAKER	ECZH0000901	24 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C305	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C306	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C307	CAP,CHIP,MAKER	ECZH0000901	24 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C308	CAP,TANTAL,CHIP	ECTH0004807	10 uF,10V ,M ,STD ,1608 ,R/TP ; , , [empty] , [empty] , -55TO+125C , , [empty] , [empty] , [empty] , [empty]		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C309	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C310	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C311	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C313	CAP,CERAMIC,CHIP	ECCH0000120	39 pF,50V,J,NP0,TC,1005,R/TP		
6	C314	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C315	CAP,CHIP,MAKER	ECZH0000901	24 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C316	CAP,CHIP,MAKER	ECZH0003503	1 uF,25V ,K ,X5R ,HD ,1608 ,R/TP		
6	C317	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C318	RES,CHIP,MAKER	ERHZ0000420	150 ohm,1/16W ,J ,1005 ,R/TP		
6	C319	RES,CHIP,MAKER	ERHZ0000420	150 ohm,1/16W ,J ,1005 ,R/TP		
6	C320	CAP,CHIP,MAKER	ECZH0001122	680 pF,50V ,K ,X7R ,HD ,1005 ,R/TP		
6	C321	CAP,CHIP,MAKER	ECZH0001122	680 pF,50V ,K ,X7R ,HD ,1005 ,R/TP		
6	C322	CAP,CERAMIC,CHIP	ECCH0000163	47 nF,10V,K,X5R,HD,1005,R/TP		
6	C323	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C324	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C401	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C403	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C404	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C405	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C406	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C408	CAP,CERAMIC,CHIP	ECCH0000143	1 nF,50V,K,X7R,HD,1005,R/TP		
6	C409	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C410	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C416	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C417	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C418	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C419	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C503	CAP,CERAMIC,CHIP	ECCH0000129	120 pF,50V,J,NP0,TC,1005,R/TP		
6	C528	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C531	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C532	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C533	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C534	CAP,CERAMIC,CHIP	ECCH0000179	22 nF,16V ,K ,X5R ,HD ,1005 ,R/TP		
6	C535	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C536	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C537	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C538	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C539	CAP,CERAMIC,CHIP	ECCH0002002	47000 pF,10V ,K ,B ,HD ,1005 ,R/TP		
6	C540	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C541	CAP,CERAMIC,CHIP	ECCH0000143	1 nF,50V,K,X7R,HD,1005,R/TP		
6	C542	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C543	CAP,CERAMIC,CHIP	ECCH0000143	1 nF,50V,K,X7R,HD,1005,R/TP		
6	C544	CAP,CHIP,MAKER	ECZH0001126	820 pF,50V ,K ,X7R ,HD ,1005 ,R/TP		
6	C545	CAP,CHIP,MAKER	ECZH0001126	820 pF,50V ,K ,X7R ,HD ,1005 ,R/TP		
6	C546	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C547	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C548	CAP,CHIP,MAKER	ECZH0000822	1.5 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	C549	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C550	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C551	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C553	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C554	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	CN202	CONNECTOR,BOARD TO BOARD	ENBY0034201	24 PIN,0.4 mm,ETC , ,GB042 H=1.0, Socket		
6	CN302	CONNECTOR,I/O	ENRY0006401	18 PIN,0.4 mm,ANGLE , ,H=2.5, Reverse Type		
6	CN401	CONNECTOR,ETC	ENZY0016301	3 PIN,3.0 mm,ETC , ,H=2.0		
6	FB201	FILTER,BEAD,CHIP	SFBH0007103	75 ohm,1005 ,CHIP BEAD, 300mA		
6	FB205	FILTER,BEAD,CHIP	SFBH0007101	120 ohm,1005 ,Ferrite Bead		
6	FB206	FILTER,BEAD,CHIP	SFBH0007101	120 ohm,1005 ,Ferrite Bead		
6	FB207	FILTER,BEAD,CHIP	SFBH0000909	60 ohm,1005 ,		
6	FB208	FILTER,BEAD,CHIP	SFBH0000909	60 ohm,1005 ,		
6	FB304	FILTER,BEAD,CHIP	SFBH0008103	1000 ohm,1005 ,chip bead, 200mA,DCR0.9ohm , ; , , SMD ,R/TP		
6	FB305	FILTER,BEAD,CHIP	SFBH0008103	1000 ohm,1005 ,chip bead, 200mA,DCR0.9ohm , ; , , SMD ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	FB306	FILTER,BEAD,CHIP	SFBH0008103	1000 ohm,1005 ,chip bead, 200mA,DCR0.9ohm ,; , , ,SMD ,R/TP		
6	FB307	FILTER,BEAD,CHIP	SFBH0007102	10 ohm,1005 ,Ferrite Bead		
6	FB500	FILTER,BEAD,CHIP	SFBH0008101	600 ohm,1005 ,		
6	FB501	FILTER,BEAD,CHIP	SFBH0008101	600 ohm,1005 ,		
6	FL301	FILTER,EMI/POWER	SFEY0007101	SMD ,1CH,1608Feedthru ESD/EMI filter for power Pb-free		
6	FL302	FILTER,EMI/POWER	SFEY0007101	SMD ,1CH,1608Feedthru ESD/EMI filter for power Pb-free		
6	FL305	VARISTOR	SEVY0008302	5.5 V,30% ,SMD ,1409Size (4CH)		
6	FL306	VARISTOR	SEVY0008302	5.5 V,30% ,SMD ,1409Size (4CH)		
6	FL307	VARISTOR	SEVY0008302	5.5 V,30% ,SMD ,1409Size (4CH)		
6	FL500	FILTER,DIELECTRIC	SFDY0002601	2450 MHz,2.0*1.25*1.0 ,SMD ,2400M~2500M, IL 3.8, 8pin, U-B, 34.2_j95, BT (CSR BC41B143A) ,; ,BPF ,2450 ,100 ,SMD ,R/TP		
6	L202	INDUCTOR,SMD,POWER	ELCP0010001	2.2 uH,M ,2.5x2.0x1.0 ,R/TP ,chip MLCI ,; , ,20% , , , , , ,NON SHIELD ,2.5X2X1MM ,[empty] ,R/TP		
6	L203	INDUCTOR,SMD,POWER	ELCP0010001	2.2 uH,M ,2.5x2.0x1.0 ,R/TP ,chip MLCI ,; , ,20% , , , , , ,NON SHIELD ,2.5X2X1MM ,[empty] ,R/TP		
6	L205	INDUCTOR,CHIP	ELCH0004703	1 nH,S ,1005 ,R/TP ,		
6	L301	INDUCTOR,CHIP	ELCH0009114	100 nH,J ,1005 ,R/TP ,coil		
6	L302	INDUCTOR,CHIP	ELCH0010302	100 nH,J ,1608 ,R/TP ,chip coil		
6	L303	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
6	L304	INDUCTOR,CHIP	ELCH0010302	100 nH,J ,1608 ,R/TP ,chip coil		
6	L307	INDUCTOR,SMD,POWER	ELCP0009404	1 uH,M ,2.8*2.6*1 ,R/TP ,Power inductor ,; ,1uH ,20% , ,1.3A ,0.072ohm , , , ,SHIELD ,2.8X2.6X1MM ,[empty] ,[empty] ,Inductor,Wire Wound,Chip		
6	L507	INDUCTOR,CHIP	ELCH0004730	33 nH,J ,1005 ,R/TP ,		
6	L508	INDUCTOR,CHIP	ELCH0003823	470 nH,K ,1608 ,R/TP ,chip coil,PBFREE		
6	L509	INDUCTOR,CHIP	ELCH0004713	6.8 nH,J ,1005 ,R/TP ,		
6	L510	INDUCTOR,CHIP	ELCH0004730	33 nH,J ,1005 ,R/TP ,		
6	L584	INDUCTOR,CHIP	ELCH0001409	10 nH,J ,1005 ,R/TP ,PBFREE		
6	Q401	TR,BJT,NPN	EQBN0017601	VMT3 ,0.15 W,R/TP ,		
6	Q402	TR,BJT,NPN	EQBN0017601	VMT3 ,0.15 W,R/TP ,		
6	R211	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R214	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	R222	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R223	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R232	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
6	R233	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
6	R301	RES,CHIP,MAKER	ERHZ0000407	1000 Kohm,1/16W ,J ,1005 ,R/TP		
6	R302	RES,CHIP,MAKER	ERHZ0000467	330 Kohm,1/16W ,J ,1005 ,R/TP		
6	R303	RES,CHIP,MAKER	ERHZ0000529	1.5 Kohm,1/16W ,J ,1005 ,R/TP		
6	R304	RES,CHIP,MAKER	ERHZ0000443	2200 ohm,1/16W ,J ,1005 ,R/TP		
6	R305	RES,CHIP,MAKER	ERHZ0000405	10 Kohm,1/16W ,J ,1005 ,R/TP		
6	R306	RES,CHIP,MAKER	ERHZ0000405	10 Kohm,1/16W ,J ,1005 ,R/TP		
6	R309	RES,CHIP,MAKER	ERHZ0000483	47 ohm,1/16W ,J ,1005 ,R/TP		
6	R310	RES,CHIP,MAKER	ERHZ0000483	47 ohm,1/16W ,J ,1005 ,R/TP		
6	R311	RES,CHIP,MAKER	ERHZ0000483	47 ohm,1/16W ,J ,1005 ,R/TP		
6	R314	RES,CHIP,MAKER	ERHZ0000439	200 Kohm,1/16W ,J ,1005 ,R/TP		
6	R315	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R316	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R320	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R401	RES,CHIP,MAKER	ERHZ0000405	10 Kohm,1/16W ,J ,1005 ,R/TP		
6	R402	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
6	R403	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R404	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R405	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R406	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R407	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R408	RES,CHIP,MAKER	ERHZ0000467	330 Kohm,1/16W ,J ,1005 ,R/TP		
6	R410	RES,CHIP	ERHY0000298	3.3M ohm,1/16W,J,1005,R/TP		
6	R411	RES,CHIP,MAKER	ERHZ0000483	47 ohm,1/16W ,J ,1005 ,R/TP		
6	R412	RES,CHIP,MAKER	ERHZ0000486	47 Kohm,1/16W ,J ,1005 ,R/TP		
6	R422	RES,CHIP,MAKER	ERHZ0000404	1 Kohm,1/16W ,J ,1005 ,R/TP		
6	R504	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	R514	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	R515	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J , 1005 ,R/TP		
6	R516	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J , 1005 ,R/TP		
6	R517	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R518	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R519	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R520	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R521	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J , 1005 ,R/TP		
6	R526	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J , 1005 ,R/TP		
6	R527	RES,CHIP,MAKER	ERHZ0000456	2.2 ohm,1/16W ,J , 1005 ,R/TP		
6	R590	RES,CHIP,MAKER	ERHZ0000496	560 ohm,1/16W ,J , 1005 ,R/TP		
6	R592	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R593	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R594	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R596	INDUCTOR,CHIP	ELCH0004721	2.2 nH,S , 1005 ,R/TP ,		
6	R597	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J , 1005 ,R/TP		
6	R598	RES,CHIP,MAKER	ERHZ0000451	27 ohm,1/16W ,J , 1005 ,R/TP		
6	R599	RES,CHIP,MAKER	ERHZ0000451	27 ohm,1/16W ,J , 1005 ,R/TP		
6	R600	RES,CHIP,MAKER	ERHZ0000236	2000 ohm,1/16W ,F , 1005 ,R/TP		
6	S401	CONN,SOCKET	ENSY0018601	16 PIN,ETC , ,2.54 mm,UIM 8P, Micro SD Dupli-Socket		
6	SW500	CONN,RF SWITCH	ENWY0002304	STRAIGHT ,SMD ,0.8 dB,MUSE MODEL		
6	U202	IC	EUSY0270602	MICRO SMD ,24 PIN,R/TP ,2BUCK 2LDO,2.5x2.5 ,; ,IC,Sub PMIC		
6	U203	IC	EUSY0343501	CSP ,42 PIN,R/TP ,Audio CODEC with Class AB,D dual speaker driver, Dual DAC ,; ,IC,Audio Codec		
6	U204	IC	EUSY0340301	uMLP ,10 PIN,R/TP ,typ Rdson 0.4ohm, 1.4X1.8 ,; ,IC,Analog Switch		
6	U301	IC	EUSY0250501	SC70 ,5 PIN,R/TP ,Comparator, pin compatible to EUSY0077701		
6	U302	IC	EUSY0338301	uMLP ,10 PIN,R/TP ,High Speed USB Siwitch 2.0 3.7pF 6.5ohm 1.4X1.8		
6	U303	IC	EUSY0264502	DFN ,14 PIN,R/TP ,700mA Boost converter ,; ,IC,DC,DC Converter		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	U401	IC	EUSY0362601	SSON004 ,4 ,R/TP ,Hall IC ,; ,IC,CMOS		
6	U502	MODULE,ETC	SMZY0015801	84 Ball 0.5pitch, BGA , Bluetooth+FM (6.0*6.0*1.0)		
6	VA201	VARISTOR	SEVY0004401	18 V , ,SMD ,40pF, 1005		
6	VA202	VARISTOR	SEVY0004401	18 V , ,SMD ,40pF, 1005		
6	VA203	VARISTOR	SEVY0004301	18 V , ,SMD ,10pF, 1005		
5	SAFD00	PCB ASSY,MAIN,SMT TOP	SAFD0106601			
6	C101	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C102	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C103	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C104	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C105	CAP,CHIP,MAKER	ECZH0001215	1 uF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C106	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C107	CAP,CHIP,MAKER	ECZH0001215	1 uF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C108	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C109	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C110	CAP,CHIP,MAKER	ECZH0001215	1 uF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C111	CAP,CHIP,MAKER	ECZH0000816	12 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C112	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C113	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C114	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C115	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C116	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C117	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C118	CAP,CHIP,MAKER	ECZH0001215	1 uF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C119	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C120	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C121	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C122	CAP,CERAMIC,CHIP	ECCH0000129	120 pF,50V,J,NP0,TC,1005,R/TP		
6	C123	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C124	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C125	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C126	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C127	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C128	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C129	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C130	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C131	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C132	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C133	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C134	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C135	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C136	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C137	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C138	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C139	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C140	CAP,CHIP,MAKER	ECZH0025502	22000000 pF,6.3V ,M ,X5R ,HD ,2012 ,R/TP , , 0.85t ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty]		
6	C141	CAP,CHIP,MAKER	ECZH0025502	22000000 pF,6.3V ,M ,X5R ,HD ,2012 ,R/TP , , 0.85t ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty]		
6	C142	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , [empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C143	CAP,CERAMIC,CHIP	ECCH0005604	10000000 pF,6.3V ,M ,X5R ,TC ,1608 ,R/TP , , [empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,[empty] ,0.8 mm		
6	C144	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C145	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C146	CAP,CHIP,MAKER	ECZH0001216	220 nF,10V ,K ,X5R ,TC ,1005 ,R/TP		
6	C147	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C201	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C202	CAP,CERAMIC,CHIP	ECCH0000122	47 pF,50V,J,NP0,TC,1005,R/TP		
6	C215	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C217	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C218	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C220	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C223	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C224	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C225	CAP,CERAMIC,CHIP	ECCH0000110	10 pF,50V,D,NP0,TC,1005,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C226	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C228	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C246	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C249	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C250	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C251	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C252	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C253	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C254	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C255	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C256	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C257	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C258	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C259	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C260	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C261	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C272	VARISTOR	SEVY0004001	18 V , ,SMD ,3pF, 1005		
6	C273	VARISTOR	SEVY0004001	18 V , ,SMD ,3pF, 1005		
6	C274	VARISTOR	SEVY0004001	18 V , ,SMD ,3pF, 1005		
6	C275	VARISTOR	SEVY0004001	18 V , ,SMD ,3pF, 1005		
6	C294	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C312	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C325	CAP,CERAMIC,CHIP	ECCH0000147	2.2 nF,50V,K,X7R,HD,1005,R/TP		
6	C326	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C327	CAP,CERAMIC,CHIP	ECCH0000198	2.2 uF,6.3V ,M ,X5R ,TC ,1005 ,R/TP		
6	C411	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C412	CAP,CHIP,MAKER	ECZH0003103	0.1 uF,10V ,K ,X7R ,HD ,1005 ,R/TP		
6	C413	CAP,CHIP,MAKER	ECZH0003503	1 uF,25V ,K ,X5R ,HD ,1608 ,R/TP		
6	C414	CAP,CHIP,MAKER	ECZH0003503	1 uF,25V ,K ,X5R ,HD ,1608 ,R/TP		
6	C415	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C500	CAP,CHIP,MAKER	ECZH0000830	33 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C510	CAP,CHIP,MAKER	ECZH0000802	1 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	C511	CAP,TANTAL,CHIP	ECTH0004804	33 uF,10V ,M ,L_ESR ,3216 ,R/TP		
6	C512	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C513	CAP,CERAMIC,CHIP	ECCH0000175	2.7 pF,50V ,B ,NP0 ,TC ,1005 ,R/TP		
6	C514	CAP,CERAMIC,CHIP	ECCH0000175	2.7 pF,50V ,B ,NP0 ,TC ,1005 ,R/TP		
6	C515	CAP,CERAMIC,CHIP	ECCH0000185	5.6 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	C516	CAP,CERAMIC,CHIP	ECCH0000185	5.6 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	C517	CAP,CERAMIC,CHIP	ECCH0000180	3.3 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	C518	CAP,CERAMIC,CHIP	ECCH0000180	3.3 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	C519	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C520	CAP,CERAMIC,CHIP	ECCH0000112	15 pF,50V,J,NP0,TC,1005,R/TP		
6	C521	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C522	CAP,CERAMIC,CHIP	ECCH0000155	10 nF,16V,K,X7R,HD,1005,R/TP		
6	C523	CAP,CERAMIC,CHIP	ECCH0000143	1 nF,50V,K,X7R,HD,1005,R/TP		
6	C524	CAP,CERAMIC,CHIP	ECCH0000117	27 pF,50V,J,NP0,TC,1005,R/TP		
6	C525	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C526	CAP,CHIP,MAKER	ECZH0000813	100 pF,50V ,J ,NP0 ,TC ,1005 ,R/TP		
6	C527	CAP,CHIP,MAKER	ECZH0001126	820 pF,50V ,K ,X7R ,HD ,1005 ,R/TP		
6	C555	CAP,CERAMIC,CHIP	ECCH0004904	1 uF,6.3V ,K ,X5R ,TC ,1005 ,R/TP		
6	C570	CAP,CERAMIC,CHIP	ECCH0000701	1.2 pF,50V ,C ,NP0 ,TC ,1005 ,R/TP		
6	CN301	CONNECTOR,BOARD TO BOARD	ENBY0039101	54 PIN,0.4 mm,ETC , ,H=1.5, P4S Socket		
6	CN304	CONNECTOR,BOARD TO BOARD	ENBY0043701	20 PIN,0.4 mm,STRAIGHT , , , , ,0.40MM ,STRAIGHT ,FEMALE ,SMD ,[empty] , ,		
6	D101	DIODE,SWITCHING	EDSY0017301	VSM ,15 V,100 mA,R/TP ,PB-FREE		
6	D102	DIODE,SWITCHING	EDSY0010001	UMD2 ,30 V,2 A,R/TP ,SCHOTTKY BARRIER DIODE		
6	D103	DIODE,SWITCHING	EDSY0010001	UMD2 ,30 V,2 A,R/TP ,SCHOTTKY BARRIER DIODE		
6	D201	DIODE,SWITCHING	EDSY0011901	EMD2 ,30 V,1 A,R/TP ,VF=1.5V(IF=200mA) , IR=30uA(VR=10V)		
6	D202	DIODE,SWITCHING	EDSY0011901	EMD2 ,30 V,1 A,R/TP ,VF=1.5V(IF=200mA) , IR=30uA(VR=10V)		
6	FB202	FILTER,BEAD,CHIP	SFBH0007103	75 ohm,1005 ,CHIP BEAD, 300mA		
6	FB203	FILTER,BEAD,CHIP	SFBH0007102	10 ohm,1005 ,Ferrite Bead		
6	FB204	FILTER,BEAD,CHIP	SFBH0007102	10 ohm,1005 ,Ferrite Bead		
6	FB301	FILTER,EMI/POWER	SFEY0010501	SMD ,SMD ,18 V,4ch. EMI_ESD Filter (100Ohm,15pF), Pb-free		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	FB302	FILTER,EMI/POWER	SFEY0010501	SMD ,SMD ,18 V,4ch. EMI_ESD Filter (100Ohm,15pF), Pb-free		
6	FB303	FILTER,EMI/POWER	SFEY0010501	SMD ,SMD ,18 V,4ch. EMI_ESD Filter (100Ohm,15pF), Pb-free		
6	FL303	FILTER,EMI/POWER	SFEY0010501	SMD ,SMD ,18 V,4ch. EMI_ESD Filter (100Ohm,15pF), Pb-free		
6	FL304	FILTER,EMI/POWER	SFEY0010501	SMD ,SMD ,18 V,4ch. EMI_ESD Filter (100Ohm,15pF), Pb-free		
6	L101	INDUCTOR,CHIP	ELCH0003827	47 nH,J ,1005 ,R/TP ,chip coil		
6	L102	INDUCTOR,CHIP	ELCH0003827	47 nH,J ,1005 ,R/TP ,chip coil		
6	L104	INDUCTOR,SMD,POWER	ELCP0007403	10 uH,M ,2.8*2.8*1.0 ,R/TP ,Coil type , Shield type		
6	L105	INDUCTOR,SMD,POWER	ELCP0007403	10 uH,M ,2.8*2.8*1.0 ,R/TP ,Coil type , Shield type		
6	L201	INDUCTOR,CHIP	ELCH0003823	470 nH,K ,1608 ,R/TP ,chip coil,PBFREE		
6	L204	INDUCTOR,CHIP	ELCH0004703	1 nH,S ,1005 ,R/TP ,		
6	L206	INDUCTOR,CHIP	ELCH0004703	1 nH,S ,1005 ,R/TP ,		
6	L207	INDUCTOR,CHIP	ELCH0004703	1 nH,S ,1005 ,R/TP ,		
6	L208	INDUCTOR,CHIP	ELCH0004703	1 nH,S ,1005 ,R/TP ,		
6	L401	INDUCTOR,CHIP	ELCH0004722	47 nH,J ,1005 ,R/TP ,		
6	L402	INDUCTOR,CHIP	ELCH0005009	100 nH,J ,1005 ,R/TP ,		
6	L403	INDUCTOR,CHIP	ELCH0004722	47 nH,J ,1005 ,R/TP ,		
6	L501	INDUCTOR,CHIP	ELCH0001056	2.7 nH,S ,1005 ,R/TP ,PBFREE		
6	L502	INDUCTOR,CHIP	ELCH0001402	18 nH,J ,1005 ,R/TP ,Pb Free		
6	L503	INDUCTOR,CHIP	ELCH0001031	15 nH,J ,1005 ,R/TP ,PBFREE		
6	L504	INDUCTOR,CHIP	ELCH0009110	5.1 nH,J ,1005 ,R/TP ,chip coil		
6	L505	INDUCTOR,CHIP	ELCH0001057	3.9 nH,S ,1005 ,R/TP ,PBFREE		
6	L570	INDUCTOR,CHIP	ELCH0004718	5.6 nH,S ,1005 ,R/TP ,		
6	L571	INDUCTOR,CHIP	ELCH0004721	2.2 nH,S ,1005 ,R/TP ,		
6	L572	INDUCTOR,CHIP	ELCH0004704	4.7 nH,S ,1005 ,R/TP ,		
6	Q201	TR,FET,N-CHANNEL	EQFN0005201	SOT-323 ,.29 W,25 V,.7 A,R/TP ,N-Channel MOSFET, Pb free		
6	Q301	TR,BJT,NPN	EQBN0017601	VMT3 ,0.15 W,R/TP ,		
6	R104	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R105	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R106	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	R108	RES,CHIP,MAKER	ERHZ0000441	22 ohm,1/16W ,J ,1005 ,R/TP		
6	R109	RES,CHIP,MAKER	ERHZ0000441	22 ohm,1/16W ,J ,1005 ,R/TP		
6	R111	RES,CHIP,MAKER	ERHZ0000477	390 Kohm,1/16W ,J ,1005 ,R/TP		
6	R112	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
6	R113	RES,CHIP,MAKER	ERHZ0000204	100 Kohm,1/16W ,F ,1005 ,R/TP		
6	R114	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R115	RES,CHIP,MAKER	ERHZ0000267	3300 ohm,1/16W ,F ,1005 ,R/TP		
6	R117	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R119	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R121	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R124	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R125	RES,CHIP,MAKER	ERHZ0000267	3300 ohm,1/16W ,F ,1005 ,R/TP		
6	R126	RES,CHIP,MAKER	ERHZ0000404	1 Kohm,1/16W ,J ,1005 ,R/TP		
6	R128	RES,CHIP,MAKER	ERHZ0000405	10 Kohm,1/16W ,J ,1005 ,R/TP		
6	R129	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R131	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R132	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R134	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R135	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R136	RES,CHIP,MAKER	ERHZ0000444	22 Kohm,1/16W ,J ,1005 ,R/TP		
6	R137	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R138	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R139	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R140	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R141	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R142	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R143	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R144	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R145	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R146	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	R147	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R148	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R149	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R150	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R151	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R152	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R153	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R154	RES,CHIP,MAKER	ERHZ0000443	2200 ohm,1/16W ,J ,1005 ,R/TP		
6	R155	RES,CHIP,MAKER	ERHZ0000443	2200 ohm,1/16W ,J ,1005 ,R/TP		
6	R204	RES,CHIP,MAKER	ERHZ0000509	75 ohm,1/16W ,J ,1005 ,R/TP		
6	R207	RES,CHIP,MAKER	ERHZ0000485	4700 ohm,1/16W ,J ,1005 ,R/TP		
6	R208	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R217	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R219	RES,CHIP,MAKER	ERHZ0000505	680 ohm,1/16W ,J ,1005 ,R/TP		
6	R220	RES,CHIP,MAKER	ERHZ0000412	1200 ohm,1/16W ,J ,1005 ,R/TP		
6	R221	RES,CHIP,MAKER	ERHZ0000463	33 ohm,1/16W ,J ,1005 ,R/TP		
6	R224	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	R226	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R227	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R228	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R229	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R230	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R312	RES,CHIP,MAKER	ERHZ0000405	10 Kohm,1/16W ,J ,1005 ,R/TP		
6	R313	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R415	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R416	RES,CHIP,MAKER	ERHZ0000404	1 Kohm,1/16W ,J ,1005 ,R/TP		
6	R417	RES,CHIP,MAKER	ERHZ0000540	7.5 ohm,1/16W ,J ,1005 ,R/TP		
6	R418	RES,CHIP,MAKER	ERHZ0000406	100 Kohm,1/16W ,J ,1005 ,R/TP		
6	R419	RES,CHIP	ERHY0000128	15K ohm,1/16W,F,1005,R/TP		
6	R420	RES,CHIP,MAKER	ERHZ0000530	5.1 Kohm,1/16W ,J ,1005 ,R/TP		
6	R421	RES,CHIP,MAKER	ERHZ0000268	33 Kohm,1/16W ,F ,1005 ,R/TP		

Level	Location No.	Description	Part Number	Spec	Color	Remark
6	R500	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R501	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R502	RES,CHIP,MAKER	ERHZ0000204	100 Kohm,1/16W ,F ,1005 ,R/TP		
6	R503	THERMISTOR	SETY0006301	NTC ,10000 ohm,SMD ,1005, 3350~3399k, J, R/T, PBFREE		
6	R505	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R507	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R508	RES,CHIP,MAKER	ERHZ0000412	1200 ohm,1/16W ,J ,1005 ,R/TP		
6	R509	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R510	RES,CHIP,MAKER	ERHZ0000434	1 ohm,1/16W ,J ,1005 ,R/TP		
6	R591	PCB ASSY,MAIN,PAD SHORT	SAFP0000501			
6	SPFY	PCB,MAIN	SPFY0174101	FR-4 ,0.8 mm,STAGGERED-10 , , , , , , , , , ,		
6	U101	IC	EUSY0294203	FBGA ,107 PIN,ETC ,FULLY 1.8V 1G(128Mx8) NAND+512M(32Mx16) SDRAM , , ,IC,MCP		
6	U102	IC	EUSY0227901	SON5-P-0.35(fSV) ,5 PIN,R/TP ,2-INPUT AND GATE, Pb Free		
6	U103	IC	EUSY0173801	SC70JW ,8 PIN,R/TP ,5 Individual Load Switch		
6	U104	IC	EUSY0347801	BGA ,293 PIN,R/TP ,EDGE RF BB PM Onchip BB , ,IC,Digital Baseband Processor		
6	U105	IC	EUSY0173801	SC70JW ,8 PIN,R/TP ,5 Individual Load Switch		
6	U201	IC	EUSY0240001	MICROPAK ,6 PIN,R/TP ,SINGLE BIT UNIT-DIRECTIONAL TRANSLATOR / PB FREE		
6	U206	IC	EUSY0351801	BGA ,193 PIN,R/TP ,5M Camera,D1,Audio,MIPI , ,IC,Digital Signal Processors		
6	U304	IC	EUSY0345201	3*3 QFN ,10 PIN,R/TP ,3xis Accelerometer , ,IC,A/D Converter		
6	U402	IC	EUSY0160401	SOT-23 ,3 PIN,R/TP ,DC MOTOR DRIVER / INTEGRATED RELAY		
6	U403	IC	EUSY0351601	DFN ,12 PIN,R/TP ,Dual Charger IC (Bypass) , ,IC,Charger		
6	U500	PAM	SMPY0017901	dBm, %, A, dBc, dB,5x5 ,SMD ,IFX Linear Edge , , , , , , , ,R/TP ,R/TP ,		
6	U501	FILTER,SEPERATOR	SFAY0011401	850.900 ,1800.1900 , dB, dB, dB, dB,4532 ,GSM Quad band FEM.		
6	X101	X-TAL	EXXY0018404	26 MHz,10 PPM,8 pF,40 ohm,SMD ,3.2*2.5*0.6 ,12ppm at -30°C ~ +85°C, C0 1.0pF, C1 3.6fF , ,26 ,10PPM ,8 , ,SMD ,R/TP		
6	X102	X-TAL	EXXY0024301	32.768 KHz,20 PPM,12.5 pF,70 Kohm,SMD ,3.2*1.5*0.9 , -40°C ~ +85°C, C0 1.05pF, C1 1fF , ,32.768 ,20PPM ,12.5 , , ,SMD ,R/TP		

14. EXPLODED VIEW & REPLACEMENT PART LIST

14.3 Accessory

Note: This Chapter is used for reference, Part order is ordered by SBOM standard on GCSC

Level	Location No.	Description	Part Number	Spec	Color	Remark
3	ADEY00	DATA KIT	ADEY0015501	KC550 DATA KIT FOR GBR	Without Color	
3	SBPL00	BATTERY PACK,LI-ION	SBPL0094902	3.7 V,900 mAh,1 CELL,PRISMATIC ,553443,INNERPACK,EUROP ,; , , , ,PRISMATIC , , ,BLACK , ,EUROP Type	Black	
		BATTERY PACK,LI-ION	SBPL0095802	3.7 V,900 mAh,1 CELL,PRISMATIC ,553443,INNERPACK,EUROP ,; , , , ,PRISMATIC , , ,BLACK , ,	Black	
3	SGDY00	DATA CABLE	SGDY0010904	; ,[empty] ,[empty] ,[empty] , 18 ,BLACK ,6.2mm Plug Databable ,[empty]		
3	SGEY00	EAR PHONE/EAR MIKE SET	SGEY0003721	; ,RMS 20mW(0.56V,RMS) ,16Ohm+/-2.4Ohm 1KHZ ,116dB+/-3dB 1KHZ,3mW ,116dB 1KHZ ,96dB 100HZ ,[empty] ,BLACK ,18P MMI CONNECTOR , ,Earphone,Stereo		
3	SSAD00	ADAPTOR,AC-DC	SSAD0025001	100-240V ,5060 Hz,5.1 V,.,7 A,CE ,AC-DC ADAPTOR ,; ,85Vac~264Vac ,5.1V ,+0.15V , -0.2V ,700mA ,5060 , ,WALL 2P ,I/O CONNECTOR ,		
		ADAPTOR,AC-DC	SSAD0025002	100-240V ,5060 Hz,5.1 V,.,7 A,CE ,AC-DC ADAPTOR ,; ,85Vac~264Vac ,5.1V +0.15V , -0.2V ,700mA ,5060 , ,WALL 2P ,I/O CONNECTOR ,		